



Agitatori Miscelatori Dispensori






MIXERS USE AND MAINTENANCE MANUAL

TABLE OF CONTENTS

1	Range of mixers	4
2	Installation Instruction	7
3	Warnings and Warranty	9
4	General Safety Recommendations	11
5	Instructions for storage	13
6	Installation	14
7	Start up	33
8	Control and preventive maintenance plan	37
9	Corrective maintenance	39
10	Troubleshooting table	40
11	CE certificate	42

SAFETY INSTRUCTIONS

These symbols    indicate the type of risk resulting from failure to observe the safety requirements:



DANGER
RISK OF ELECTRIC
SHOCK

Warning that failure to comply with the requirements may cause electric shocks or electrocution



DANGER
GENERIC

Warning that failure to comply with the requirements may cause harm to people and objects.



WARNING

Warning that failure to comply with the requirements may cause damage to the mixer or other equipment.


1 - THE RANGE OF MIXERS

VERTICAL MIXERS: Their application is very flexible

They differ according to the driving set. The size depends on the torque (power divided by number of revs)

The seal options are shared by the entire range.

The fast series is used for smaller tanks or to carry out dispersions

<p>FAST AV MODEL Driving set: Aluminium spider with bearing Motor position: Vertical Rotation speed: 750÷1500 RPM Flow rate: 60-1400 m³/h Power: 0.12-18.5 kw Shaft diameters: 15-65mm</p>	
<p>SLOW AVF MODEL (small sizes) Driving set: Worm screw gearbox Motor position: Horizontal Rotation speed: 50÷280 RPM Flow rate: 50-2700 m³/h Power: 0,12-4 kw Shaft diameters: 25-50mm</p>	
<p>SLOW AVC MODEL (large sizes) Driving set: Orthogonal bevel gearbox Motor position: Horizontal Rotation speed: 15÷250 RPM Flow rate: 1500-30000 m³/h Power: 1.1-45 kw Shaft diameters: 40-100mm</p>	
<p>SLOW AVL MODEL (large sizes) Driving set: Parallel axis gearbox Motor position: Horizontal Rotation speed: 15÷250 RPM Flow rate: 1500-30000 m³/h Power: 1.1-45 kw Shaft diameters: 35-100mm</p>	
<p>SLOW AVS MODEL (large sizes) Driving set: Coaxial gearbox Motor position: Vertical Rotation speed: 15÷360 RPM Flow rate: 100-50000 m³/h Power: 0.25-22 kw Shaft diameters: 25-120mm AVS1÷4: Coaxial with cylindrical gears AVS5÷11: Coaxial with epicycloidal gears AVSm5÷9: Coaxial with cylindrical gears with additional bearing for longer shafts AVSh5÷9: Coaxial with epicycloidal gears with additional bearing for longer shafts</p>	

AV	F	2	-	0.37	/ 80	v	-	AC	-	Y	L	X
----	---	---	---	------	------	---	---	----	---	---	---	---













Table 1: Impellers					
Axial impellers					
	Sabre KVA T (T) High efficiency three-blade axial impeller with thin blades	Pag T1 (A) High efficiency three-blade axial impeller with wing profile	Marine (M) High head, ideal solution for direct mixers with impellers that are smaller than the diameter of the tank	Sabre KVA C (C) Impeller with high flow and head, for side mixers or viscous products	Axial turbine (P) Used to give a cutting action to the products (preparation of solutions) and for average viscosities
Radial impellers					
	Radial turbine (R) A flexible solution to create the cutting action required at both slow and fast speeds - ideal as a base impeller with very low head	Rusthon turbine (H) Very powerful impeller, generates shear and flow rate. Ideal for gas dispersion in liquid	Cowles (S) It provides cutting action only to disperse insoluble products - often coupled with a marine that recirculates the product		

Table 2: Materials	
A	Carbon steel
—	SS304
Y	SS316L
D	SS904L
E	SAF 2205
F	SAF 2501
G	Hastelloy
H	Rubber-coated
I	Ebonite-coated
J	Abcrite-coated
K	PP-coated
L	Halar-coated
M	PFA-coated
N	SS304 polished
O	SS316L polished

Table 3: Seal system					
Without stool		Single, with stool		Double, with stool	
L	Lip	L	Lip		
B	Packing	C	Packing		
	graphite/NBR (side) Without Seal (vertical)				
W	hard surfaces/NBR				
V	graphite/Viton	S	graphite/Viton	D	graphite/Viton
WV	hard surfaces/Viton	SW	hard surfaces/Viton	DW	hard surfaces/Viton
E	graphite/EPDM	SE	graphite/EPDM	DE	graphite/EPDM
WE	hard surfaces/EPDM	SWE	hard surfaces/EPDM	DWE	hard surfaces/EPDM
T	graphite/PTFE	ST	graphite/PTFE	DT	graphite/PTFE
WT	hard surfaces/ PTFE	SWT	hard surfaces/ PTFE	DWT	hard surfaces/ PTFE



Mechanical seal within the process, without stool



Short stool for cartridge seal



Tall stool for double seal

Further possibilities:

F: removal of seal without removing the reduction gear

H: Shut off system to maintain pressure in the system while replacing the seal

2 – INSTALLATION INSTRUCTION

POSITIONING ON THE TANK

CENTRAL INSTALLATION IN TANKS WITH CIRCULAR BASE




(needed for suspension of solids and thermal exchange)

The internal wall of the tank must be added the same number of vertical breakwaters as the impeller's blades.

The aim is to break the whirl generated by the rotation and to create a totally axial motion, as per drawing

Distance from the wall: $A = T/36$

Breakwater width: $B =$ viscosity function as per table ($T/12$ for low viscosity applications)



INSTALLATION WITHOUT BREAKWATERS

Breakwaters are an additional cost and they are not allowed for sanitary applications.

There are three ways to avoid to use them:

- 1) For smaller tanks or tanks where the D/T ratio, between the impeller's and the tank's diameters is low (< 0.3), it is possible to install an offset mixer, that is vertical with distance from the axis of $0.16 \div 0.25$ times the tank's diameter (Fig. a)
- 2) When the D/T ratio is too high and the impeller would be too close to the wall, so the mixer can be inclined of max 10° towards the centre, as per Fig. b, in this case we have $A = 0.28 T$ and $B = 0.165 T$
- 3) If the tank has a rectangular base, the corners function as breakwaters. If the rectangle is very long, it is possible to install two mixers, each of them placed at the centre of a semi-rectangle




Fig. a




Fig. b




Fig. c


DISTANCES FROM THE EDGES

In order for the mixer to work to its best, the impeller with diameter D must not be too close to the walls and to the surface of the liquid at minimum level

S: Distance of the end of the impeller from the wall (it determines the length of the shaft): Min 150mm

C: Distance of the impeller from the bottom or from another impeller: Min $0.25 D$ (usually between 0.5 and $1.5 D$)

L: Minimum level of the liquid above the impeller: $0.5 D$ (usually D)



INSERTION OF THE IMPELLERS

The bolted impellers must be fitted on the shaft, at the last moment, inside the tank, so an opening of at least 500 mm is necessary for the operators to go in.

For welded impellers (the smaller ones, coated with acid-proof material or for the food industry), the possibility to fit them in the tank already mounted on the shaft should be verified.

In case of impellers which are already welded to the shaft, the minimum diameter required usually is little smaller than the impeller diameter; whereas, for dowelled impellers the minimum passageway required is about $2/3$ of the diameter, according to the nozzle length.

If a sufficient opening is not available in the tank, there are only two possibilities:

- On-site welding of the minimum number of blades (in order to fit the impeller, it is usually sufficient not to weld the last blade)
- Close the tank after having fitted the shaft with the welded impellers.

In case of difficult assembly condition, a 2D or 3D simulation can help.

Max passage diameter in case of impeller taken off from the shaft (indicative measures in mm)				
Nozzle	Internal diameter	Three-blade impeller with thin blades	Three-blade impeller with large blades	Four-blade impeller
DN150	170	260	160	160
DN200	220	340	220	250
DN250	270	430	250	300
DN300	320	520	350	400
DN400	410	660	450	500
DN500	510	800	500	650
DN600	610	950	600	800

3 - WARNINGS AND WARRANTY

3.1 - Introduction

The purpose of this manual is to provide the necessary information for the safe installation, use and maintenance of the mixer.

The mixer is designed and built for industrial use and therefore must only be installed and used by qualified personnel who are familiar with applicable directives and standards of practice generally recognised.

The user should read this entire manual before using the mixer.

Improper use may damage the mixer and invalidate the warranty.



The mixer is NOT a “ready-to-use machine”, but is a component of a POTENTIALLY HAZARDOUS system, as it is equipped with unprotected rotating parts which, in case of contact, can cause serious harm to people and objects. All uncovered rotating parts of the mixer must be segregated or protected so that it is impossible to make contact with people or objects when the motor is powered. The responsibility for the safety of the finished machine and compliance with all applicable laws and directives belongs to the manufacturer or assembler incorporating the mixer as a component.

It is strictly forbidden to put the mixer into service before the machine into which it will be incorporated is declared compliant with applicable safety regulations.

When requesting technical support or spare parts from our offices, always communicate the model and serial number indicated on the mixer data plate.

The following instructions and warnings refer to our standard mixer models with three-phase electric motor. For any special variant or version, pay particular reference to the annexes and the documents of sale.

For questions or situations not described in this manual or other documents of sale, please contact our office.

3.2 - Warranty

With effect from the date of delivery, GREC S.r.l. guarantees the mechanical parts of the machine, in normal conditions of use and service, for a period of 12 MONTHS.

THIS WARRANTY DOES NOT COVER PARTS SUBJECT TO WEAR

The warranty is understood as replacement of the faulty part ex GREC Srl works.
The costs of transporting and installing the new piece are charged to the customer.
Any commercial terms agreed in the order have precedence over this declaration.

3.3 - Liability

The manufacturer declines all responsibility in the following cases:

- mixer use which does not comply with national safety and accident prevention laws
- incorrect installation, failure to follow the instructions in this manual correctly
- power supply faults
- modifications or tampering
- operations carried out by untrained or unsuitable personnel.

The safety of the machine also depends on careful observation of the requirements listed in the manual, and in particular it is necessary to:

- always operate within the envisaged limits of use
- always ensure diligent regular maintenance
- assign operators who are trained for the purpose to inspection and maintenance
- use original spare parts only

The instructions in this manual do not replace but supplement the requirements of the applicable legislation regarding safety standards.

The mixer is designed to operate with fluids with the characteristics (density, viscosity, temperature etc.) specified in the contract documents (e.g. order confirmation). In the absence of such specifications, it is the responsibility of the installer to check the compatibility of the mixer and its components (e.g. mechanical seals, gaskets etc.) with the fluids and operational characteristics to which it is subjected.



Working with fluids other than those specified in the contract documents or in operating conditions other than those listed in the contract documents or in the next paragraph can cause harm to the mixer and/or people and/or surrounding property.

4 - GENERAL SAFETY RECOMMENDATIONS

READ THIS SECTION CAREFULLY BEFORE STARTING TO USE THE MIXER. FAILURE TO OBSERVE THESE RECOMMENDATIONS MAY CAUSE HARM TO PEOPLE OR OBJECTS.
IF YOU DO NOT UNDERSTAND ANY PART OF THESE INSTRUCTIONS, DO NOT ATTEMPT TO INSTALL OR OPERATE THIS MIXER. CONTACT GREC SRL FOR ANY PROBLEM.

4.1 - Moving and Lifting

- Use suitable lifting devices only. Do NOT attempt to lift the mixer by hand if it weighs more than 20 kg.

4.2 - Connecting the power supply

- Do not connect the motor to the power supply until all components have been assembled, the mixer has been installed and all the bolts have been tightened to the values specified in the manual.
- Do not touch the mixer or the power cable if you have wet hands or feet or if you are in contact with a wet or damp surface.
- Before performing any maintenance, unplug the power supply.

4.3 - Use

- Always check that lubricant is present in the gearbox, bearings and mechanical seal where necessary according to the manual.
- Assemble all protections that ensure that it is not possible to touch moving parts of the mixer (shaft, motor, impellers, seal, gaskets etc.) with hands or any part of the body.
- Do not use the mixer for purposes other than those envisaged. Do not operate the sealing system at temperatures or pressures higher than those specified.
- BEFORE operating the mixer, it is very important to check the following:
 - ensure that the mixer is connected to the earthing network
 - ensure that all safety devices (butt straps etc.) are installed.
 - ensure that all removable parts are firmly secured.
 - read the instructions provided with the mixer carefully.
 - ensure that the rotating parts are free of obstacles, by rotating the mixer by hand.
 - ensure that all external connections (electrical, hydraulic, pneumatic etc.) have been made according to current regulations.
 - DO NOT ENTER the tank unless the motor is disconnected and the mixing shaft is firmly secured to the mixer or supported from below.

4.4 - Maintenance

- Do not make any change to the mixer (installed power, rotation speed, shaft length, impellers etc.) without consulting GREC SRL.
- Unplug the motor from the power supply before performing any maintenance.
- When repairing the mixer or replacing parts, use only procedures and components approved by GREC SRL.
- Do not touch the mixer motor or the top of the mixing shaft unless they have been left to cool for at least an hour.

To perform maintenance in areas that are not easily accessible or hazardous, ensure adequate safety for those performing maintenance and others in compliance with applicable laws regarding safety in the workplace.

Maintenance, inspection and repairs may only be performed by experienced maintenance technicians, aware of dangerous conditions. It is therefore necessary to provide operating procedures

for the complete machine aimed at managing the dangerous situations that could arise and methods for preventing them. The experienced maintenance technician should always work very carefully, paying close attention and carefully following the safety rules.


During operation wear only clothes and/or individual safety equipment indicated in the instructions for use provided by the Manufacturer and by applicable laws on safety at work.


Replace worn components using original spare parts. Use oils and greases recommended by the Manufacturer. Do not dispose of polluting materials into the environment. Dispose of these materials in compliance with applicable laws on this matter.


After replacing the lubricants, clean the surfaces of the gearbox and the floor around to the working area.


4.5 - Electric motor


Low voltage motors are intended for industrial plants and comply with harmonised standards EN 60034/IEC34. If not expressly indicated, use is prohibited in classified areas due to danger of explosion and fire. The motors are suitable for room temperatures ranging between -20°C and +40°C and places with altitude up to 1,000 m a.s.l.

 Carefully check the data indicated on the plate before commissioning the motor. Low voltage motors are considered as components to be installed in other machines according to Machinery Directive 2006/42/EC. Their commission is prohibited until conformity to this directive is demonstrated. The rotating electrical machines, powered from the mains, comply with standards EN 50081 and EN 50082 regarding electromagnetic compatibility phenomena - Directive 2004/108/EC. No special shielding measures are required. In the event of intermittent operation, any interference generated by the insertion devices must be limited using suitable wiring.

 Operations on the electrical machine must be carried out with the machine stopped and disconnected from the mains (including the auxiliary equipment). In the presence of electrical protection devices, prevent sudden restarts, complying with the specific recommendations on the use of the various devices.

 Electrical connection operations must be carried out by qualified personnel, with motor stopped and disconnected, and with no chance this can be restarted. The rotor is balanced dynamically with half key. The coupling components must be balanced with half key on smooth spindle. Joints and pulleys must be mounted with specific equipment in order to not damage the motor bearings. After assembly check that the coupling components are fixed on the shaft end and pushed against the stop. If the hub of the coupling component is shorter than the end of the shaft, the difference can be compensated by a spacer bushing. Too small or too large pulleys compromise the proper operation of the bearings. The motors must be installed to allow the cooling air to enter and exit easily. Ventilation must not be prevented and the exhaust air, also the adjacent units, must not be re-suctioned by the fan. Prevent heat sources from affecting the air and motor temperature. In the event of indoor installation, protect the motor from solar radiation and bad weather with suitable devices. We recommend protecting the motor with motor protection devices and torque electronic limiters if the motor is not equipped with thermistors. In the presence of extreme temperature changes and condensation, the motor must be equipped with condensation heaters and drain holes made according to the installation position.

 The electrical connection must always be carried out by qualified personnel, in compliance with the applicable EEI, EN 60204 and possible local regulations.

 Always refer to the data on the voltage and frequency plate, in order to ensure a correct connection with the power supply network. If not specified, tolerance can be of $\pm 5\%$ on the voltage and $\pm 1\%$ on the frequency values indicated in the plate. The connection diagrams are normally provided with the motor or are printed in the terminal box. Should they be missing, refer to those provided in the manual.

5 - INSTRUCTIONS FOR STORAGE

FAILURE TO COMPLY WITH THE FOLLOWING RECOMMENDATIONS FOR STORAGE AND PROTECTION MAY INVALIDATE ANY IMPLICIT OR EXPLICIT WARRANTIES.

5.1 – General Instructions

- Upon receipt of your mixer, check for any damage caused by shipping and report any problems to the carrier and to our factory.
- All unpainted steel parts are coated with a protective layer which can be easily removed using kerosene or another solvent.
- Do not remove any protection if the mixer is to be placed in storage before being installed. Store the mixer in a clean, dry place, with air circulation which is not subject to rapid, considerable changes in temperature.
- If storage continues for more than a year, check the condition of the gearbox lubricant before putting the mixer into service.

5.2 – Recommendations for prolonged storage

GREC SRL mixers must be protected against corrosion during prolonged periods of inactivity. The main cause of corrosion is the condensation formed due to high humidity and/or temperature changes.

The machines therefore have to be stored properly in a clean, dry place.

Electric motors must never be stored outdoors. In the event of prolonged inactivity, refer to the manufacturer's recommendations and check for condensation, removing it if necessary.

The mechanical seal (if fitted) is not filled with lubricant (if necessary). Refer to the seal maintenance section for instructions.

For storage over 6 months, it is necessary to fill the gearbox to the top with oil to protect internal parts and seals against corrosion.

5.2.1 - STORING EQUIPMENT WITH RUBBER OR EBONITE-COATED SHAFTS AND IMPELLERS

The following instructions must be complied with for all coated mixers that remain in storage prior to installation and commissioning for a period exceeding three months.

Proper storage of coated components should take place in closed storerooms where the temperature never drops below 0 °C.

Where coated shafts and impellers must remain in storage for longer than three months, it is advisable to protect the coating from solar radiation (light and UV rays).

If storage must last for over a year, components with cavities must be filled periodically with water and it should be ensured that they remain full.

If it is impossible to store coated shafts and impellers in closed storerooms, it is possible to use outdoor storage, carefully following the recommendations depending on environmental temperatures.

Storage in cold climates

Equipment must be packed in wooden crates with a minimum thickness of 30 mm and a layer of waterproof paper inside them.

Crates must be placed directly in close contact with the ground, making sure not to leave spaces below in order to exclude air infiltration. They must be close together so as not to leave spaces between them. The crates must then be fully covered with waterproof sheets without slits or tears. The sheets must be properly anchored to the ground and sealed. When sizing the crates, it is advisable to bear in mind the extra weight caused by any snowfall. It is advisable not to handle coated equipment or stress it mechanically in any way when the ambient temperature is below 0 °C.

Storage in temperate or hot climate countries

The components of the mixers that are coated with rubber or ebonite and which have cavities must be capped, completely filled with water, checking periodically that they remain full. All equipment must be covered with sheets, making sure, for the parts normally exposed to sunlight, that an air chamber is created between the sheet and the equipment itself to limit the rising heat. This chamber can be made with wooden frames or with metal scaffolding.

6 - INSTALLATION

6.1 - Identification

Upon receipt of the mixer, check that the package is intact.

After unpacking, make sure that there is no transport damage (check the linearity of the shafts in particular).

If the mixer is damaged, draw up a report countersigned by the carrier or at least write "conditional acceptance" on the shipping document. DO NOT install the mixer and notify GREC Srl within three working days.

Note data from the machine identification plate, present on the machine itself, and check that this coincides with that given on the drawings. Remember to always quote the serial number located on the plate for any communication with the manufacturer.

It must always be possible to read all the data shown on the identification plate, and the plate must be cleaned periodically.

If the plate deteriorates and/or is no longer legible, even as regards a single set of data elements, it is recommended to request a new one from the manufacturer, quoting the data contained in this manual, and replace it.

GREC	GREC S.r.l. - Piazza della Conciliazione, 2 I 20123 Milano - Italy www.grec.it	CE
Agitatore / Mixer		
Tipo / Type	<input type="text"/>	
Matr. / Serial n.	<input type="text"/>	
Anno <input type="text"/>	Item	<input type="text"/>

6.2 - Handling

The mixer should be handled with care using appropriate lifting systems.

Do not lift the mixer by its fragile components (terminal boxes, knobs etc.) and **do not use any eye bolts installed on the motor, gearbox, variator etc.** These eyebolts are only to be used for lifting the component to which they are connected when this is separated from the rest of the machine. Do not use the mixer shaft either. If this bends, it could cause vibration and damage to the mixer itself and to the tank.

The best way to lift the mixer is to sling the motor, or even better the spider, if any, properly.

Be careful not to bump or handle any mechanical shaft seal.

If the shaft or other parts are coated with rubber, PTFE, PVC or similar, due to the high fragility of these materials, we recommend only removing the protective cover when installation is completed.

Place the machine in position following these rules for moving:

- ◇ Secure all parts that could come loose or fall out of the machine.
- ◇ Remove any accessories affixed to the machine.
- ◇ Make sure there is enough space for moving the machine and the lifting system.
- ◇ Lift the machine carefully
- ◇ The transport operation must be performed by specialised personnel.

Some important rules to be followed:

1 - Ensure that the mixer support plate is level: an angle of the support that does not exceed a maximum offset of 1 mm from the vertical geometry is tolerated for every metre of shaft length.

2 - Another important aspect of installation is that the support should be as rigid as possible to prevent any degree of freedom of the structure from causing unwanted stresses on the rotating machine, amplifying the stress of the shaft and bearings.

A SUPPORT THAT IS TOO WEAK MAY LEAD TO THE BREAKAGE OF THE SHAFT OR ANY OTHER MECHANICAL PART OF THE MACHINE IN A SHORT SPACE OF TIME.

All stages of installation must be considered, from the creation of the general design. The person authorised to perform such work must, if necessary, implement a “safety plan” to ensure the safety of the people involved and apply all existing laws to the letter.

3 - Clean any packaging residues and any protective products from the gearbox. Pay particular attention to the coupling surfaces.

4 - Check correct shaft/shaft or shaft/hole alignment.

5 - Provide adequate safety protections devices for the rotating parts outside the gearbox.

6.3 – Assembly and Disassembly for Maintenance



6.3.1 Preliminary checks

- Check that the data on the identification plate matches that in the technical specification
- Check the oil level in the gearbox and that there are no visible leaks
- Check that the rated voltage and current are compatible with those available
- Position any safety guards
- Check for and remove any moisture on the motors after prolonged storage
- Check to see if the mixer is designed to operate at constant or variable level, and if breakwaters are required
- Ensure that the mixer cannot start up accidentally

6.3.2 Positioning

Before installing the mixer, it is necessary to verify the following:

- The space available around and above the tank/container, taking into account the length of the shaft and the space required for cooling the motor.
- The rigidity and appropriate size of the mixer support structure, considering the static and dynamic loads. The mixer must not vibrate or oscillate during operation.
- If being installed outdoors, the motor must be protected from rain and direct sunlight.
- The size of the openings in the tank for the introduction of the impellers, drains etc.

6.3.3 Securing

The mixer must be securely attached to its support by bolts, clamps or other suitable devices. The bolts must always be the maximum size allowed by the attachment point provided on the mixer.

The mixer consists of a control unit and a mixing unit.

The **control unit** consists of motor, gearbox or spider, and seal system.

If there are no special reasons agreed upon with the Customer, the control unit is shipped already assembled, ready to be erected and placed on the tank or container plate.

The interfaces available are the tank fixing flange and connection joint between control unit and mixing unit.

For AVL, AVF, AVC models, no joint is available if the gearbox is with hollow shaft and the seal system is with lip or missing. The mixing unit shaft is inserted automatically in the gearbox hollow and it is fixed with the attached screws.

For models with or without mechanical retainer but with protruding shaft (AVS, AVSh, AVSm), or in the presence of base guides, use a joint to the shaft, which can be a sleeve (economic for smaller sizes) or flanged (easier to dismantle).

The **mixing unit** is usually composed of two main parts:

shaft (in one or more sections), one or more impellers, base guide (if any).

Different shaft sections are connected by flanged joints.

6.3.4 Vertical mixer with Base guide

The base guide is the last component to be installed and its support is made depending on the position of the mixer shaft. It is essential to ensure that the shaft and the bushes are perfectly in line and that, when the shaft is turned by hand, there is no friction between it and the bushes.



IMPORTANT: THE GUIDE MUST NEVER BE OPERATED DRY, BUT MUST BE LUBRICATED BY THE CONTENTS OF THE TANK OR OTHER LIQUID.

1.1. The base guide is designed to ensure long service life. The service life of the wear bushing is influenced by many factors and can vary greatly even in installations that are similar.

1.2. Excessive wear can affect the proper operation of the mixer and cause damage to other components, therefore it is important to carry out initial tests to estimate the average life expectancy and consequently the inspection and/or maintenance intervals.

1.3. In any case, we recommend checking the conditions of the guide at least once a year.

THE BASE GUIDE DRAWING WITH THE INSTALLATION INSTRUCTIONS IS ALWAYS SENT DURING THE ORDER STAGE.

6.3.5 Maintenance


Operations different from the assembly may be required if maintenance of the machine is needed. It can be carried out on the gearbox or on the sealing system

6.3.6 Possible configurations of the control unit

SE RI AL		NUMBER	SEAL	STOOL	SHUT OFF	SHAFT JOINT	CHARACTERISTIC
1	VERTICAL	AVS1÷4	No	No	No	With sleeve	Economic
2		AVS5÷11, AVSm, AVSh	No	No	No	Flanged	Easier to dismantle
3		AVF, AVL, AVC	No / With lip	Yes/No	No	No	Simple and economic
4		AVF, AVL, AVC	With cartridge	Yes	No	Flanged	Standard solution
5		AVF, AVL, AVC	With cartridge	Yes	No	No	Solution for hygienic environment
6		AVL, AVC	With cartridge	Yes	Yes	Flanged within the stool	Seal replacement with gearbox in position
7		AVS	With cartridge	Yes	Yes	Spacer within the stool	Seal replacement with gearbox in position
8		AVS	Hydraulic guard	Yes	No	Flanged	Economic solution for P< 0.05 barg

1

Vertical mixer without seal, sleeve joint fixing system, AVS1÷4 series




Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Sleeve joint
5	Dowels
6	Shaft
7	Impeller
8	Securing of the impeller

A) ASSEMBLY

- 1 - The motor and the sleeve joint are already secured to the reduction gear
- 2 - Secure the geared motor unit to the support beam (the reduction gear flange has a centring mark)
- 3 - Insert the shaft (6) into the sleeve joint (5) and tighten the fitted dowels
- 4 - Secure the impeller (7) to the shaft

2

Vertical mixer without seal, flanged joint fixing system, AVS5÷11, AVSm, AVSh series.




Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Flanged joint
5	Fixing screw
6	Shaft
7	Impeller
8	Securing of the impeller

A) ASSEMBLY

- 1 - The motor and the flanged hub are already secured to the reduction gear
- 2 - Secure the geared motor unit to the support beam (the reduction gear flange has a centring mark)
- 3 - Couple the shaft hub with the hub protruding from the reduction gear and tighten the fixing screws
- 4 - Secure the impeller (7) to the shaft

3

Vertical mixer with lip seal (or without seal), without stool, series AVF, AVL, AVC with hollow shaft



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Fixing washer
5	Protection
6	Fixing screw
7	Connection flange
8	Radial seal inserted in the flange
9	Shaft
10	Impeller
11	Securing of the impeller
12	Anti-rotational key

A) ASSEMBLY

1-Insert the shaft (9) and the impeller (10) in the tank

2 -The shaft (9) has a threaded hole in the head. For considerably heavy shafts, it is necessary to secure an eyebolt in order to use lifting chain, which must pass into the reduction gear hollow shaft.

Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant

Lift the shaft, carefully passing it through the flange (7), the seal (8) and the hollow shaft of the reduction gear (2).

3- Once the shaft touches the end of travel of the reduction gear bottom, insert the anti-rotational key (12), if not already inserted in the hollow of the shaft. Then insert the upper locking ring (4) and tighten the screw head (3).

4- Protect the exposed rotating part with a cover (5).

5- Secure the flange (7) of gear motor unit to the tank flange having the same dimensions.

6- For mixers without seals, the procedure is the same, but without components (7) and (8)

7-For mixers with lip or stool seal, the procedure is the same. The stool is used to separate the reducer from a very hot tank roof, to allow the shaft to be cooled.

B) REPLACEMENT OF THE REDUCTION GEAR

1-Dismantle the motor (1) from the reduction gear (2) if needed

2-Carefully loosen the screw (3), slowly lowering the shaft until it rests inside the tank

3-Remove the screw (3), washer (4) and key (12).


3-Unbolt the reduction gear from the flange (7) and take it to maintenance

C) REPLACEMENT OF THE SEAL

1-Once the reduction gear has been taken off, remove the radial seal (8) by hand

4

Vertical mixer with cartridge seal, stool, flanged joint within the process, AVF, AVL, AVC series



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Fixing washer
5	Protection
6	Stool
7	Connection flange
8	Cartridge seal
9	Shaft
10	Flanged joint
11	Anti-rotational key
12	Fixing screw

This configuration allows you to obtain an economical solution, especially for smaller sizes.

The guide unit travels with the seal already mounted to facilitate installation; however, maintenance of the reduction gear or seal must be carried out in the workshop, removing the entire driving set from the tank.

A) ASSEMBLY


- 1-Insert the shaft and the impeller in the tank
- 2- Secure the flange (7) of gear motor unit to the tank flange having the same dimensions.
- 3-Lift the shaft matching the two faces of the flanged joints (10) and tighten the fixing screws (12)
- 4-Fit the impellers

B) REPLACEMENT OF THE REDUCTION GEAR AND THE SEAL


- 1-Remove the shaft from the flanged joint, placing it inside the tank
- 2-Remove the geared motor unit and take it to the workshop
- 3-Loosen the bolts of the mechanical seal (8)
- 4-Carefully loosen the screw (3), passing the shaft (9) through the seal (8)
- 5-Remove the screw (3) and the washer (4)
- 6-Dismount the motor (1) and reduction gear (2)
- 7-Remove and replace, if required, the mechanical seal (8)

5

Vertical mixer (hygienic version) with cartridge seal, stool, without flanged joint within the process, AVF, AVL, AVC series



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Fixing washer
5	Protection
6	Stool
7	Connection flange
8	Cartridge seal
9	Shaft
10	Impeller
11	Securing of the impeller
12	Anti-rotational key
13	Split support ring



A) ASSEMBLY

1-Insert the shaft (9) and the impeller (10) in the tank

2- Secure the flange (7) of gear motor unit to the tank flange having the same dimensions.

3 -The shaft (9) has a threaded hole in the head. For considerably heavy shafts, it is necessary to secure an eyebolt in order to use lifting chain, which must pass into the reduction gear hollow shaft.

Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant

Lift the shaft, carefully passing it through the flange (7), the seal (8) and the hollow shaft of the reduction gear (2).

ATTENTION: the sealing surfaces of the fixed and rotating seats are lapped with a mirror finish. It is vital that they are handled with care and kept perfectly clean.

Lubricate with silicone grease and slide the mechanical seal onto the shaft, taking care not to damage it.

4- Once the shaft has reached the end of travel on the bottom of the reduction gear, secure the shaft support collar (13), making sure that the dowels are in line with the marks made on the shaft and trace the shaft to allow the collar (13) to rest on the flange (7).

5-Remove the eyebolt and insert the anti-rotational key (12), if not already inserted in the specific hollow shaft. Then insert the upper locking ring (4) and tighten the screw head (3).

6- Protect the exposed rotating part with a cover (5).

B) REPLACEMENT OF THE REDUCTION GEAR


- 1-Dismantle the motor from the reduction gear, if needed
- 2-Carefully loosen the screw (3), slowly lowering the shaft until the support ring (13) rests on the flange (7)
- 3-Remove the screw (3), washer (4) and key (12).
- 3-Unbolt the reduction gear from the stool (6) and take it to maintenance

C) REPLACEMENT OF THE SEAL

- 1-Dismantle and remove the support ring (12)
- 2-Dismantle and lift the cartridge seal (8) up to under the reduction gear
- 3-Fit back the support ring (12) under the seal
- 4-Dismantle the reduction gear according to procedure B
- 5-Replace / maintain the cartridge (8),
- 6-Fit back the reduction gear according to procedure A
- 7-Dismantle and remove the support ring (12)
- 8-Secure the cartridge (18) to the flange (7)
- 9-Fit back the support ring (8)

6

Vertical mixer with cartridge seal, stool, flanged joint within the stool to remove the seal without touching the reduction gear, AVL, AVC series



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Fixing washer
5	Protection
6	Stool
7	Connection flange
8	Cartridge seal
9	Shaft
10	Impeller blades
11	Impeller hub
12	Anti-rotational key
13	Shut off rotating part
14	Shut off stationary part
15	O ring
16	Welded flanged
17	Dismantling flange
18	Guide shaft
19	Guide shaft retainers

For larger mixers, it is better to replace the mechanical seal without intervening on the geared motor unit.

This is why a higher spider is made to receive a flanged joint and leave the space to remove the seal through the side windows.

The mechanical seal is mounted together with the flange and stool, which are separated by the driving set.

The shut off prevents pressure loss from the tank during the maintenance phases.

A) ASSEMBLY

- 1-Insert the shaft (9) and the impeller (10) in the tank
- 2- Secure the flange (7) of seal unit to the tank flange having the same dimensions.
- 3-Insert the fixed part (14) on the shaft and the rotating part (13) on the shut off. Fasten the latter making sure that the dowels are aligned with the marks made on the shaft.
- 4- The shaft (9) has a threaded hole on the head, to which an eyebolt is secured in order to use the lifting chain. Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant
Lift the shaft and carefully make it pass through the flange (7) and seal (8).



ATTENTION: the seal surface of the fixed and rotating seat are lapped with finish. Lubricate with silicon grease and slide the mechanical seal on the shaft paying attention not to damage it.

- 5- Once the shut off has reached the bottom of the flange, secure it to the flange and lower the shaft with the rotating part of the shut off (13) on the fixed part (14).
- 6-Remove the eyebolt
- 7-If not already on the hollow of the shaft, insert the anti-rotational key (12) and removable flange (17). Then insert the upper locking ring (4) and tighten the screw head (3).
- 8-Mount the driving set (1+2), lowering the guide shaft (18) into the stool (6) and tightening the bolts between reduction gear flange and stool flange.
- 9-Insert the bolts in the flanged joint (16+17) and, by tightening them, lift the shaft by a few millilitres to separate the two components (13 and 14) of the shut off and proceed assembling.

B) REPLACEMENT OF THE REDUCTION GEAR

- 1-Dismantle the motor from the reduction gear, if needed
- 2-Slowly remove the screws of the flanged joint, making the rotating part of the shut off (13) rest on the stationary part (14)
- 3-Remove the screws between reduction gear flange and stool flange
- 4-Remove the reduction gear

C) REPLACEMENT OF THE SEAL

- 1-Loosen the fixing bolts of the mechanical seal (8)
- 2-Carefully loosen the screw (3) of the guide shaft (18), lowering the shaft slowly until the rotating part of the shut off (13) rests on the stationary part (14)
- 3-Remove the screws from the flanged joint (16+17)
- 4-Lift the guide shaft (9) inside the cavity of the reduction gear and insert the shaft stops (19) into the spider, so that the shaft is kept lifted
- 5-Remove the removable flange (17) loosening and removing screw (3), washer (4), and key.
- 6-Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant
- 7-Remove the mechanical seal (8) through the spider openings




ATTENTION: the seal surface of the fixed and rotating seat are lapped with finish. Lubricate with silicon grease and slide the mechanical seal on the shaft paying attention not to damage it.

- 8-If the seal (8) is too heavy, place some rails on the stool to make the seal slide outside the stool.
- 9-Replace / Maintain the cartridge (8),
- 10-Proceed with the opposite phases for the assembly

7

Vertical mixer with cartridge seal, coaxial reduction gear, spacer joint within the stool to remove the seal without touching the reduction gear, AVS series



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Fixing washer
5	Anti-rotational key
6	Stool
7	Connection flange
8	Cartridge seal
9	Shaft
10	Impeller blades
11	Impeller hub
12	Flanged joint fixing bolts
13	Shut off rotating part
14	Shut off stationary part
15	O ring
16	Flanged spacer joint
17	Dismantling flange

For larger mixers, it is better to replace the mechanical seal without intervening on the geared motor unit.

This is why a higher spider is made to receive a spacer joint and leave the space to remove the seal through the side windows.

The mechanical seal is mounted together with the flange and stool, which are separated by the driving set.

The shut off prevents pressure loss from the tank during the maintenance phases.

A) ASSEMBLY

- 1-Insert the shaft (9) and the impeller (10) in the tank
- 2- Secure the flange (7) of seal unit to the tank flange having the same dimensions.
- 3-Insert the fixed part (14) on the shaft and the rotating part (13) on the shut off. Fasten the latter making sure that the dowels are aligned with the marks made on the shaft.
- 4- The shaft (9) has a threaded hole on the head, to which an eyebolt is secured in order to use the lifting chain. Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant
Lift the shaft and carefully make it pass through the flange (7) and seal (8).



ATTENTION: the seal surface of the fixed and rotating seat are lapped with finish. Lubricate with silicon grease and slide the mechanical seal on the shaft paying attention not to damage it.

- 5- Once the shut off has reached the bottom of the flange, secure it to the flange and lower the shaft with the rotating part of the shut off (13) on the fixed part (14).
- 6-Remove the eyebolt
- 7-If not already on the hollow of the shaft, insert the anti-rotational key (12) and removable flange (17). Then insert the upper locking ring (4) and tighten the screw head (3).
- 8-Mount the driving set (1+2), lowering the spacer joint (16), already mounted on the reduction gear (2) into the stool (6) and tightening the bolts between reduction gear flange and stool flange.
- 9-Insert the bolts (12) in the flanged joint (16 and 17) and, by tightening them, lift the shaft by a few millilitres to separate the two components (13 and 14) of the shut off and complete the assembling.

B) REPLACEMENT OF THE REDUCTION GEAR


- 1-Dismantle the motor from the reduction gear, if needed
- 2-Slowly remove the screws (12) of the flanged joint, making the rotating part of the shut off (13) rest on the stationary part (14)
- 3-Remove the screws between reduction gear flange and stool flange
- 4-Remove the reduction gear

C) REPLACEMENT OF THE SEAL

- 1-Loosen the fixing bolts of the mechanical seal (8)
- 2-Carefully loosen the screw (12) of the flanged joint (16+17), lowering the shaft slowly until the rotating part of the shut off (13) rests on the stationary part (14)
- 3-Remove the screws of the flanged joint, also in the upper connection, and remove the spacer joint (there is space because the centring mark of the joint has a lower value at half the distance between the fixed and rotating component of the shut off)
- 4-Remove the removable flange (17) loosening and removing screw (3), washer (4), and key.
- 5-Wrap the part of the shaft with the hollow key with a thin ribbon and spread with lubricant
- 6-Lift the mechanical seal (8) through the spider openings
ATTENTION: the seal surface of the fixed and rotating seat are lapped with finish. Lubricate with silicon grease and slide the mechanical seal on the shaft paying attention not to damage it.
- 7-If the seal (8) is too heavy, place some rails on the stool to make the seal slide outside the stool.
- 8-Replace / maintain the cartridge (8),
- 9-Proceed with the opposite phases for the assembly

8

Vertical mixer with siphon seal, coaxial reduction gear, AVS series



Pos	Description
1	Electric motor
2	Reduction gear
3	Fixing screw
4	Flanged joint
5	Fixing screw
6	Rotating part of the siphon
7	Tank connection flange
8	Impeller
9	Shaft
10	Flanged stool (supplied by the customer)
11	Barrier liquid inlet (supplied by the customer)
12	Barrier liquid outlet (supplied by the customer)
13	Level Meter (supplied by the customer)
14	Siphon stationary part (supplied by the customer)

For larger mixers, when the shafts are very long and pressure can be checked from a small head (< 0.05 barg = 50 cm of water), it is convenient to use a siphon seal, provided by the customer, except for the siphon rotating part (inverted cup, which must be secured to the mixer shaft).

A) ASSEMBLY

- 1-Insert the shaft (9) and the impeller (8) in the tank
- 2-The seal unit, provided by the customer, is already mounted on the tank roof
- 3- The shaft (9) has a threaded hole on the head, to which an eyebolt is secured in order to use the lifting chain. Lift the shaft and carefully make it pass through the stationary part of the siphon (14).
- 4- Once the shaft has reached an area of the roof that can be managed, fasten the rotating part of the siphon (6), making sure that the dowels are aligned with the marks made on the shaft, and the removable flange, complete with key, washer and head screw.
- 5- Gently lower the shaft until the rotating part of the siphon (6) rests on the stationary part and remove the eyebolt
- 6-Fasten the flange of the reduction gear to that of the stool.
- 9-Insert the bolts (5) in the flanged joint (4 and 17) and, by tightening them, lift the shaft by a few millilitres to separate the two components of the siphon and proceed assembling.

B) REPLACEMENT OF THE REDUCTION GEAR

- 1-Dismantle the motor from the reduction gear, if needed
- 2-Slowly remove the screws (5) of the flanged joint, making the rotating part of the siphon (6) rest on the fixed part, which is welded to the connection flange
- 3-Remove the screws between reduction gear flange and stool flange
- 4-Remove the reduction gear


6.3.7 Mixing unit

The shaft is secured to the driving set by following the rules set-out in the previous paragraph.

Shaft-impellers assembly follows the rules set out below:

1. For **uncoated** mixers, shaft/impeller assembly is effected by tightening the screws or dowels provided.
2. If the mixer is coated (or with impellers welded to the shaft), the shaft and the impeller(s) form a single component; therefore, as the physical separation of the components is not possible, it is necessary to insert the whole unit into the tank with extreme care to prevent damage to the coating.
3. Check the minimum opening through which the impeller, or its parts (if removable), can be inserted.
4. Depending on the type of impeller, respect the position direction of the propeller on the shaft, as shown in the mixer drawing.
5. Remove the film that protects against oxidation from the parts machined using the machine tool.
6. It is good practice to make sure that dowels and nuts tightened during the assembly do not come loose during operation, using mechanical or chemical material that is compatible with the process and maintenance.

Below we describe the possible configurations:

SE RI AL NU MB ER	IMPELLER TYPE	HUB BLADE FIXING	SHAFT HUB FIXING	CHARACTERISTIC
1	Single piece, welded to the shaft	No	No	Sanitary/coated. Attention to the possibility to insert the shaft/impeller unit in the tank
2	Single piece Passing hub	No	With dowels in radial position	 Simple
3	Single piece Threaded blind hub	No	Tightened with flat gasket	Sanitary
4	Blades bolted to the hub	Bolts	With dowels in radial position Optional key	For greater diameters, when the manhole cannot be sufficient for insertion of the impeller in single piece
5	Split disc radial	Bolts	With dowels in radial position Optional key	For greater diameters, when the manhole cannot be sufficient for insertion of the impeller in single piece
6	Single piece Threaded blind hub	No	To be tightened to the shaft with bolts Optional key	For tube shafts or impellers with large diameter
7	Special	Special	Special	Assembly instructions provided during the job order phase

IMPELLER SECURED TO THE SHAFT USING DOWELS

In the case of impellers attached to the shaft using dowels, it is good practice to mark the shaft at the dowels after positioning the impellers, taking care not to drill the shaft completely when it is expected in the tube.

IMPELLERS WITH BOLTED BLADES

The impellers are shipped disassembled to facilitate transport and installation of the mixer.

To secure the blades to the hub, rest the three blades under the hub fins and insert the bolts with washers and nuts.

The blades are placed under the hub in the normal configuration with pumping downwards; on the contrary, they must be placed above the hub if pumping is upwards.

Important: before tightening the bolts, make sure that the ends of the blades are well supported on the hub fins. Furthermore, after tightening the bolts, make sure the blades have not moved along the hub fins.

It is essential that the torque of the bolts is suitable. It is equally important to keep the bolts tightened, given that the impellers are often subject to intense and variable stress, due to the reaction to the fluid forces.

To secure the hub to the shaft, cover the shaft with lubricant to facilitate moving the impeller, and then slide it upwards until reaching the holes obtained on the shaft and tighten the dowels.

The GREC three-blade hubs can be mounted in one direction or the other and have been designed to operate with clockwise shaft rotation (seen from the motor).

The concave part of the blades must be in the thrust direction (normally downwards), considering the clockwise rotation direction of the shaft seen from the top.


The outriggers, installed only on the bottom impellers, must face downwards.


The stabilising fins at the impeller ends (Pag T1) must face the opposite direction of the flow, therefore upwards.

IMPELLERS WITH THREE PIECES TO TIGHTEN TO THE SHAFT


With the three-piece impeller, first assemble the shaft in the correct vertical position, coupled to the geared motor, then assemble the three parts that make up the impeller on the ground. Then lift up the slung impeller and insert it into the shaft from below until reaching the position shown on the drawing and secure the bolts using a torque wrench with suitable calibration for the diameter of the bolts themselves and their material.

When the bolts are being tightened, check the clearance between the fins, so that the bolts are kept tight.







ALETTE DELLE PALE DEVONO ESSERE RIVOLTE VERSO L'ALTO




167	DADO T.E. (9)
166	GROWER (9)
165	VITE A TESTA ESAGONALE (9)
163	VITE (1+3 DIPENDE DAL DIAMETRO)
161	MOZZO
160	PALE (3)
117	ALBERO AGITATORE

POS.	DESCRIZIONE
------	-------------



SEZIONE B-B

Ricavato da

Oggetto ASSIEME GIRANTE A FLUSSO ASSIALE MOZZO IN UN PEZZO SOLO PALE IMBULLONATE				Disegno n°		Rev.
				Q.TA' N° 1	ARTICOLO N°	
 GREC S.r.l. Via Copernico, 3 20082 Binasco (MI) ITALY Tel.: +39 02 36645050	 SCALA NO	MATERIALE	DISEGNATORE MM	DATA 10/10/2011		
		FORMATO FOGLIO A3	COMMESSA N°	CLIENTE		
		A termini di legge questo disegno non può essere rimodificato o mostrato a terzi senza ns. autorizzazione scritta				

A termini di legge questo disegno non può essere riprodotto o mostrato a terzi senza ns. autorizzazione scritta

6.3.8 Fixing torque

Inadequately or improperly tightened bolts may become loose due to vibration or stress due to the fluid being mixed. This can shorten the life of the equipment or cause damage or failure.

The recommended fixing torques for the nuts and bolts of the mixers and their supports are listed in the table below. These values should be considered only as a guide and may require changes in special cases.

However, except where otherwise stated, always tighten the nuts and bolts of the mixers and their supports to the values shown in the table.

	stainless steel	Steel 8.8
Bolt - Pitch	Fixing Torque (Nm)	Fixing Torque (Nm)
M10	30	50
M12	50	80
M14	85	130
M16	120	200
M18	180	280
M20	240	400
M22	320	600
M24	400	700
M27	650	1000
M30	800	1400

The above mentioned values are for standard bolts and lubricated threads; for non-lubricated threads, multiply these values by 1.3.

All bolts should be coated with oil, grease or a protective substance whenever possible.

When couplings with locking elements are used, add 15% to the indicated values.

All the bolts should be inspected and tightened again after two weeks of work under load and then at every planned stop.

7- START UP

7.1. - preliminary checks

- Make sure the shaft turns manually from the motor fan.
- Make sure there are no obstacles to the movement of the shaft and impeller.
- Check the distance between the impellers and between them and the bottom and the walls

7.2 - Electrical connections



Before starting to work on the mixer, make sure that the electrical power supply is disconnected and can not be accidentally reconnected.

First connect the earthing cable (yellow/green).

It is recommended to install a high sensitivity (30 mA) differential switch, as an auxiliary protection against lethal electric shocks, in case earthing connection is not correctly working. Make sure the power supply voltage corresponds to the rated one

The electrical connection must always be carried out by qualified personnel, in compliance with the applicable EEI, EN 60204 and possible local regulations.

Always refer to the data on the voltage and frequency plate, in order to ensure a correct connection with the power supply network. If not specified, tolerance can be of $\pm 5\%$ on the voltage and $\pm 1\%$ on the frequency values indicated in the plate. The connection diagrams are normally provided with the motor or are printed in the terminal box. Should they be missing, refer to those provided in the manual.

The identification plate shows the following data:

- power supply voltage
- three-phase winding, connection (Y) or (Δ)
- current consumption under normal load

The motors are calibrated for voltage with $1:\sqrt{3}$ ratio; e.g. 380/660 V Δ/Y , and can be started in the following ways:

- direct insertion in the network with line voltage equal to the lower voltage value indicated on the identification plate (" Δ " triangle connection of the winding).
- direct insertion in the network with line voltage equal to the higher voltage value indicated on the identification plate ("Y" star connection of the winding).
- Indirect insertion in the network by means of star-triangle switch (after having removed the connectors from the terminal box), with line voltage equal to the lower voltage value indicated in the identification plate. Make sure that, in the presence of star/triangle start up, the switch from star to triangle is performed only when the start up current corresponds to the star value. This is important to prevent risk of overloads not allowed.

Connect the motor to the mains via a multi-polar switch or other device that ensures multiple disconnection (breaking all the electric wires) from the mains, with a contact gap of at least 3 mm.


Remove the cover of the motor terminal box.

Make connections as shown in the back of the terminal box cover or as indicated in the following page. – Use certified cable glands for the area in which it the mixer is installed.


The electric power supply to the motor must be fitted with a thermal-magnetic circuit breaker or magnetic starter with overload and minimum voltage protections, a thermal relay and fuses installed upstream by the installer. The overload relay must be set to the rated motor current.

Connection of the terminal box to the power supply


TRIFASE 1 VELOCITA' 2-4-6-8 POLI (6 fili)




TRIFASE DOPPIA VELOCITA' 1 AVVOLGIMENTO



TRIFASE DOPPIA VELOCITA' AVVOLGIMENTI SEPARATI



If the motor is fitted with a thermal protector, connect the protector's cables to an auxiliary contact of the contactor on the power supply line



7.3 - Checking the direction of rotation

The direction of rotation can also be checked before filling up the tank.

In the presence of a seal dipped in the liquid (AL series mixers) it is only possible to activate the motor for brief moments.



The mixer should not be started (if not specified in the sales documents) if the impeller is immersed in settled solids.

The direction of rotation is usually clockwise if seen from the motor towards the impeller. However, the correct direction of rotation is indicated on the mixer by an arrow.

If necessary, reverse the direction of rotation exchanging the position of any two wires of the power supply (this is true only for three-phase electric motors. Refer to the relevant manuals for the other motor types)

7.4 Operation Checks

Before starting the mixer, it is also necessary to perform the following checks:



- Check that all screws and bolts are tightened.
- Vent the air in the area of the mechanical seal, if necessary.
- Check that all moving parts are inaccessible and all their guards are properly installed.
- For mixers with double mechanical seal: check the connections of tubes and accessories. Start up and, if necessary, check correct the flow of the flushing or cooling system (read the relative manual).

For vertical mixers, it is necessary to carry out an initial empty run in order to verify current consumption, surface temperature (after 30 minutes of operation) and rotation speed), the possible
Then values can be compared with those resulting from the first water test.

The functional test must be carried out setting the actual operating conditions, including any tank pressurisation

Immediately after the first start up of the mixer, check the following:

- Check that the mixer does not produce "strange" noises. If it does, stop it immediately and discover and prevent the causes before restarting it.
- Check that the mixer does not produce evident vibrations or oscillations. If it does, stop it immediately and discover and prevent the causes before restarting it.

-Check that there are no leaks of oil, grease, water or other fluids. If there are, stop the mixer immediately and discover and prevent the causes before restarting it.
-Measure the voltage at the motor terminals and check that it is within the limits shown on the data plate.
-Measure the current consumption on each phase and make sure it is less than the rated value shown on the motor data plate

. The motor must never be overloaded.

Immediately stop the motor in case of:

- smoke and flames from the motor or the electrical system,
- motor overheating,
- sharp decrease in the motor speed,
- damaged fan,
- damaged starting device,
- other reasons, when a further operation of the motor or of the starting device causes damages to the environment.

In case of installation of motors with B14 flange, make sure the length of fixing bolts is appropriate for the hole diameter and depth: screws which are too long may cause damage to the motor winding.

8 - CONTROL AND PREVENTIVE MAINTENANCE PLAN



Before performing any work on the mixer, ensure that:

- **The motor power supply is completely disconnected and cannot be restored accidentally.**
- **The tank where the mixer is installed is not pressurised or under vacuum.**
- **The surfaces of the mixer and/or the tank are not hot or iced.**
- **Any vapours or odours that may escape from the tanks are not dangerous to humans or the environment.**

COMPONENT	CONTROL	LUBRICATION	REPLACEMENT
Motor			
Surface cleaning	Eliminate dust every 1,000 hours		
Eliminate condensation	Periodically		
Oil seal	1,000 hours / 2 months		When necessary
Rotation	Start up		
Vibrations	Start up		
Temperature	Regularly		
Gearbox			
Surface cleaning	Eliminate dust every 1,000 hours		
Eliminate condensation	Periodically		
Oil check	1,000 hours / 2 months	When necessary	10,000 hours
Oil seal	1,000 hours / 2 months		When necessary
Temperature	3 hours before starting up + regularly (never 70°C more than ambient temperature)		
Rotation	Start up		
Bearing support spider			
Surface cleaning	Eliminate dust every 1,000 hours		
Bearing replacement	7000 hours		7000 hours
Seal			
Stuffing box	Periodically	Normal leakage 2-3 drops/min	
Temperature	Regularly		
Temperature sensor visual check	1,000 hours / 2 months		
Visual check of the seal lubricant control system	1,000 hours / 2 months		
Seal emission check (if necessary)	100 hours / 1 week		
Mixing unit			
Bolt torque	100 hours after starting up + regularly		

Use this table as a guide, but always refer to the manufacturers' manuals of the individual components

8.1 Lubrication

MOTOR BEARINGS

Pre-lubricated, double coating bearings (type 2Z) are filled with a quantity of grease which is sufficient for the whole operating duration. Once the motor's warranty time has expired, it is advisable to replace the bearings. Motors where the lubricators are fitted on the bearing guards should be periodically lubricated. This table indicates the lubrication intervals, type and quantity of grease needed:

Mechanical size	Quantity of grease for re-lubrication [g]	Lubrication intervals [h]	
		1,500 revs/min.	3,000 revs/min.
90	4	2500	1500
100	5	2500	1500
112	7	2500	1500
132	10	1500	1000
160	12	1500	1000
180	17	1500	1000

GEARBOXES

Gearboxes are lubricated with Poli-alchil-glicole (PAG)-based synthetic oil, with EP additives, ISO320, for instance SHELL OMALA S4WE320 or equivalent

They allow an excellent performance of the gearbox with ambient temperatures from -20° to 90°C.



Be careful to use always the same type of oil, since it is not compatible with neither mineral, nor polyolefin-based synthetic oils.

Oil can be replaced with a lower viscosity one (ISO VG150) only for operation at temperatures under -30°C

Equivalent lubricants can be:

AGIP Blasia S320

ESSO Glicolube 320

Total Carter SY 320

BP Enersyn SG-XP 320

The replacement frequency depends on the actual temperature oil operates at. Higher frequency is recommended for epicycloidal gearboxes, AVS5÷11 and AVSh5÷9 models, where quantities are little and there is a cask

T oil	Operating frequency (hours)	Maximum calendar time
< 65°C	20,000	4 years
< 80°C	15,000	3 years
>90°C	9,000	2 years
Running-in	No replacement	

A more frequent oil change can be necessary also in case of difficult operating conditions, such as:

- wide and fast fluctuations in ambient temperature
- harmful vapours, chemical fumes, dusty or particularly wet atmospheres.

The gearbox is always delivered full of oil; the indicative quantities for oil change are listed in the table.

All the gearboxes whose oil is to be changed are equipped with filling and emptying caps and with visual inspection window. When the mixer has not run for 30 minutes and oil is cold, the oil level should be at the midpoint of the inspection window.



For the shipping, the filling cap and its breather are never fitted on the machine in order to avoid oil leakage. The blind cap must be replaced before the machine is started for the first time.

9 - CORRECTIVE MAINTENANCE

The machine components subject to wear are the seals and the bearings.

They are designed to last long in time if they are correctly maintained.

However, it is not possible to set a precise life duration for these components, since it depends on actual working hours, temperature and pressure, loads applied, corrosiveness of the environment and rotation speed.

A good preventive maintenance avoids the need for corrective maintenance, but if it becomes necessary, follow the safety procedures

- Switch off the mixer and make sure it cannot turn on for any reason
- Use a signboard to signal the ongoing maintenance
- Mark the current position with a felt-tip pen to be able to restore it when assembling (electrical and mechanical connections)
- Use a mechanical lifting device
- Dismantle the reduction gear and fit a support device to the mixer shaft
- Lift the unit until the shaft is accessible and can be dismantled
- If possible, remove the motor and empty the gearbox from oil
- If possible, remove the mechanical seal.

Follow the instructions given in the manufacturer's manual for the maintenance of mechanical seal, motor and gearbox.

When in doubt, contact GREC S.r.l.

In case of operation in a potentially explosive area, always take the machine needing maintenance to a safe area and, before opening the tank, make sure that the intervention cannot alter the safety conditions of the environment.

It is expedient and advisable to replace bearings and oil seals only. In case other parts are damaged, e.g. shafts or gears, it may be advisable to purchase a new component.



Always check on the plate that the installed gearbox is that indicated in the previous page, otherwise request the list of parts subject to wear to GREC Srl

10 - TROUBLESHOOTING TABLE

Problem	Probable cause	Possible solution
1) The mixer will not start	a) No electrical power supply	Provide electrical power supply
	b) Inadequate fuses (low rated current)	Replace fuses with other appropriate ones
	c) Blown fuses due to damaged motor or wires	Repair the motor or replace the cables
	d) Overload protection device previously triggered	Reset the protection device (if it is triggered again, see Problem 2)
	e) Broken gears	Replace gearbox
2) Overload protection device triggered	a) Incorrect calibration value	Adjust the calibration value or replace the protection device
	b) Phase missing	Check the power supply and fuses
	c) Deposits on the rotating parts or impellers immersed in solid sediments	Remove deposits and sediments from the impellers
	d) The density or viscosity of the lubricant is higher than recommended	Change oil
	e) The density or viscosity of the product being mixed is higher than expected	Contact the manufacturer for help
	f) Faulty bearings	Grease or change the bearings
3) The motor or gearbox heat up a lot (surface temperature 70° higher than ambient temperature)	a) Incorrect machine sizing	Check the selection and replace the component
	b) Excessive axial force on the shaft of the mixer	Check the pressure in the tank. It must be less than or equal to that indicated in the technical specification.
	c) Excessive temperature of the product to be mixed	Check the temperature of the product to be mixed. It must be less than or equal to that indicated in the technical specification.
	d) Excessive ambient temperature	Check the ambient temperature. It must be less than or equal to that indicated in the technical specification.
	e) Incorrect level or viscosity of the lubricant	Top up or replace the lubricant
	f) Oil too old	Check the lubricant replacement table
	g) Bearing play too high or defective bearings	Replace bearings
	h) Faulty motor fan or relative grille too dirty or insufficient space for the cooling air to pass through	Check the motor fan, clean the grille and make sure that the cooling air can circulate freely.
	i) The motor is overloaded and the overload protection is faulty or incorrectly adjusted	See Problem 2) and check the overload protection

4) Excessive noise. Anomalous operation. Excessive motor vibrations	a)	The impeller(s) rotate in the air or cavitate due to the low level of liquid	Increase the level of the liquid and keep it as constant as possible
	b)	Unbalanced impeller(s) (blades bent, worn or encrusted)	Check the impeller(s) and replace or clean if necessary
	c)	Bent shaft	Check the linearity of the mixer shaft and contact the manufacturer for help if necessary
	d)	Faulty bearings (the machine whistles)	Grease or replace the bearings
	e)	Faulty motor fan	Replace the motor fan
	f)	Gears are dented (cyclic noise)	No practical problems
	g)	Incorrect coupling of the motor with the machine	Adjust the position of the motor
	h)	Loose fixing screws	Tighten all the fixing screws
5) The motor speed under load decreases (slippage increases)	a)	Rotor or fan seizure	Find and eliminate the faults (rotor, belt pulley, clutch, fan) and carefully balance them.
	b)	Short-circuit in the winding	Find and eliminate the short-circuits, pre-load the motor again
	c)	Fault towards the earth	Find and eliminate the short-circuits, pre-load the motor again
	c)	Connection or winding interruption	Find and eliminate the interruptions
	c)	Single-phase power supply	Check the voltage between the terminals in the terminal box
6) Oil leakage from the gearbox	a)	Oil level not suitable for the construction form	Check and eliminate the excessive oil if necessary
	b)	Overpressure due to missing air bleeding	Add an air bleeding device for the assembly position set
	c)	Faulty seals or seals which are not suitable for the temperature	Replace seals
7) Mixing is insufficient or non-existent	a)	The impeller blades are bent, worn or encrusted	Check and clean or replace the impeller if necessary
	b)	The impeller is not installed in the correct way	Check that the impeller is installed in the correct way
	c)	Incorrect direction of rotation	Reverse the direction of rotation
	d)	Liquid characteristics and tank size are different from those indicated in the technical specification	Contact the manufacturer for help
8) Current asymmetry in power supply cables	a)	Short-circuit in the winding	Find and eliminate the short-circuits, pre-load the motor again
	b)	Fault towards the earth	Find and eliminate the short-circuits, pre-load the motor again
	c)	Connection or winding interruption	Find and eliminate the interruptions
	d)	Single-phase power supply	Check the voltage between the terminals in the terminal box



GREC S.r.l., Viale Lombardia, 16/N
20081 Cassinetta di Lugagnano (MI) – ITALY
Tel. +39 02 3664 5050
Fax +39 02 3664 5054
info@grec.it; www.grec.it

Tax ID. / VAT n. / Reg. Register
of Companies of Milan
06972530965
R.E.A. of Milan n. 1926397
Reg. Cap.: 90,000.00€ f.p.

DECLARATION OF INCORPORATION

(In compliance with Directive 2006/42/EC, annex II, par. 1, sub. B)

THE MANUFACTURER

GREC SRL		Viale Lombardia, 16/N	
Company		Address	
Cassinetta di Lugagnano	20081	Milan	ITALY
City	Post code	Province	State

WITH RELEVANT TECHNICAL DOCUMENTATION AUTHORISED BY

Marco Mariano		Legal Representative	
Name		Role	
Viale Lombardia, 16/N		20081	Milan
Address		Post code	Province
Cassinetta di Lugagnano		ITALY	
City		State	

DECLARES THAT THE PARTLY COMPLETED MACHINERY

AV... series mixer

AL... series mixer

TD.. series turbodisperses

The intended use being: Installation in a container/tank containing liquids to be mixed

It complies with the following applied essential safety requirements:

1.1 - General considerations; 1.3 - Protection measures against mechanical dangers; 1.4 - Required characteristics for protection devices; 1.5 - Risks due to other dangers; 1.6 - maintenance; 1.7 - Information

And it complies with the Community directive:

2006/42/EC (Directive for Machineries)

and with harmonised standards EN ISO 12100:2010 (Machinery safety)

It is also stated that:

- the relevant technical documentation has been drawn up in compliance with annex VII B
- we commit to send via mail or e-mail, following a duly justified claim by the national authorities, the relevant information about this partly completed machinery

IT IS FORBIDDEN

to put it into service until the final machine it has to be incorporated to has been declared complying with directive 2006/42/EC and its regulations, where applicable.

Place and date

Cassinetta di Lugagnano, 01/01/19

The legal Representative

Marco Mariano